

1. Carefully clean parts of any wiskers or flashing
2. Cut frame from sprue & glue it to the base; let dry
3. Cut Base from sprue.
Note: The cap has a tiny location lobe that should align with the gap in the frame.
4. Glue base & frame into the top cap; let dry.
5. Clean out the hole with a needle OR a #70 - 72 drill.
6. NOW cut the complete stand from the sprue.
7. Remove the lever from the sprue.
8. Glue the lever into place, between the “ribs” on top of the cap.
9. Glue the target of your choice, to the .020 wire.
10. Insert the target & wire into the .020's hole through both the cap and the base of the switch stand.



